



NOTES:

1. APPLICATION OF APPROPRIATE HYDROSEAL PRIMER MUST PRECEDE APPLICATION OF HYDROSEAL FLASHING AND DECK MEMBRANES.
2. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.



HydroSeal
Deck Membrane

AMERICAN HYDROTECH, INC.

TYPICAL PARAPET DETAILS

SCALE: NONE
DATE: 07/19

HS-11A