



NOTES:

1. APPLICATION OF APPROPRIATE HYDROSEAL PRIMER MUST PRECEDE APPLICATION OF HYDROSEAL FLASHING AND DECK MEMBRANES.
2. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.
3. NOT ALL POSSIBLE PARAPET/CURB TERMINATION CONDITIONS CAN BE DEPICTED. CONSULT HYDROTECH FOR ALL ATYPICAL CONDITIONS.
4. SCUPPER INSERTS BY OTHERS. ALL METAL SLEEVES MUST BE INSTALLED IN ONE PIECE OR COMPLETELY WELDED WATERTIGHT.
5. FOR CAST-IN-PLACE OPENINGS, W/ OR W/O INSERT, CAST OPENING MUST BE MINIMUM 4" X 4" OR 4" DIAMETER.

	<p>HydroSeal Deck Membrane</p>
<p>AMERICAN HYDROTECH, INC.</p>	

<p>TYPICAL THRU-WALL SCUPPER FLASHING</p>	
<p>SCALE: NONE DATE: 07/19</p>	<p>HS-14</p>

This information is intended only for general conceptual purposes. It is based on data and knowledge considered to be true and correct. It is offered for the user's consideration, investigation and verification and is not intended to substitute for the advice provided by appropriate professionals. Hydrotech assumes no liability for the use of this information. The determination of the suitability and applicability of this information is the sole responsibility of the user.