


NOTES:

1. TO ACCOMMODATE DEEPER INTENSIVE SOIL DEPTHS, INSTALLATION OF A "SOIL STOP" WILL TYPICALLY BE REQUIRED. THE SOIL STOP CAN BE PRECAST OR POURED-IN-PLACE CONCRETE CURBS, LANDSCAPING TIMBERS, ETC. IF SECUREMENT OF THE SOIL STOP IS NECESSARY, A CONCRETE FOOTING CAN BE POURED USING THE GR30/GR50 AS THE FORM. APPROPRIATE LOADING CALCULATIONS MUST BE VERIFIED BY THE PROJECT ENGINEER.
2. THE VEGETATION FREE ZONE (VFZ) MAY BE COMPOSED OF TYPICAL STONE BALLAST OR CONCRETE PAVERS. CONTACT HYDROTECH FOR BALLAST DESIGN REQUIREMENTS. VFZs ARE REQUIRED AT ALL ROOF PERIMETERS AND ALL PENETRATIONS (PIPES, SKYLIGHTS, ETC.). GARDENEDGE METAL EDGE RESTRAINT, CONCRETE CURBS, LANDSCAPE TIMBERS, ETC. MAY BE USED AT VFZ/GROWING MEDIA TRANSITIONS.
3. CONTACT HYDROTECH FOR VEGETATION FREE ZONE WIDTH AND MATERIAL REQUIREMENTS FOR WIND WARRANTY.



AMERICAN HYDROTECH, INC.

TYPICAL INTENSIVE GARDEN ROOF TERM. DETAIL (i.e. WALL, CURB, PIPE)

SCALE: NONE
DATE: 11/01/17

GA-3

This information is intended only for general conceptual purposes. It is based on data and knowledge considered to be true and correct. It is offered for the user's consideration, investigation and verification and is not intended to substitute for the advice provided by appropriate professionals. Hydrotech assumes no liability for the use of this information. The determination of the suitability and applicability of this information is the sole responsibility of the user.