



NOTES:

1. BALLAST DESIGN MAY REQUIRE WIDER PERIMETER VEGETATION FREE ZONES OF STONE OR CONCRETE PAVER BALLAST. CONTACT HYDROTECH FOR BALLAST DESIGN REQUIREMENTS.
2. IF NO STYROFOAM INSULATION IS INSTALLED, THE DRAINAGE MAT BELOW THE GARDNET MUST BE CHANGED TO HYDRODRAIN 302 AND INSTALLED OVER THE HYDROFLEX RB II.
3. NUMBER OF STOPS AND NUMBER AND LENGTH OF REQUIRED TENDONS IS DETERMINED BY MEDIA DEPTH AND DEGREE & LENGTH OF SLOPE.
4. LITETOP GROWING MEDIA IS REQUIRED FOR ALL GARDNET INSTALLATIONS. NO SUBSTITUTIONS ARE ALLOWED.
5. GARDNET CELLS SHALL BE OVERFILLED WITH LITETOP MEDIA BY 1/2"-1".
6. GARDMAT EROSION MAT SHALL BE INSTALLED WHEN PLANTING PLUGS. NO GARDMAT IS REQUIRED WHEN INSTALLING INSTAGREEN CARPET, TILE OR LAWN SOD.
7. PROJECT ARCHITECT/ENGINEER IS RESPONSIBLE FOR PROPER STRUCTURAL DESIGN OF ALL ROOF PARAPETS, EDGINGS AND GRAVEL STOPS TO PROVIDE SUFFICIENT DRAINAGE AND STRENGTH TO PREVENT MOVEMENT OF GARDEN ROOF COMPONENTS.



AMERICAN HYDROTECH, INC.

TYPICAL BOTTOM OF SLOPE
GARDNET TERMINATION AT WALL
(WITH STYROFOAM INSULATION)

SCALE: NONE
DATE: 8/17/2020

GN-6B

This information is intended only for general conceptual purposes. It is based on data and knowledge considered to be true and correct. It is offered for the user's consideration, investigation and verification and is not intended to substitute for the advice provided by appropriate professionals. Hydrotech assumes no liability for the use of this information. The determination of the suitability and applicability of this information is the sole responsibility of the user.